

FAQ GMSplus How to Retrieve Logfiles

1. Introduction

• This procedure describes how to retrieve Logfiles of a GMSplus.

2. Required Tools

- GMSplus
- Computer with access to GMSplus

3. Retrieve Logfiles from GMSplus

• Logfiles from GMSplus can either be retrieved from GeoDAS (3.1), through the webinterface (3.2) or from GMSplus SD-card (3.3)

3.1 Retrieve Logfiles from GeoDAS

In GeoDAS window Stations: General Information, right-click on the station and choose Instrument Control... -> Send
 a Request -> GETLOG -> [Send]

| Action or a command | Send a Request | Send |
|--------------------------------|--|--------------------------|
| Request and parameters | GETLOG | ~ |
| E. Canal unanadificantly. | | |
| Send unconditionally | 1 | |
| Sends a user request to the in | l nstrument. Enter parameters as advi | ised below |

• A .txt file with file prefix LOG_ and date- and timestamp of the request will be uploaded to the Incoming folder of your GMSplus (C:\GeoDAS_DATA\Incoming\Serial_Number_of_GMSplus)



3.2 Retrieve Logfiles from Webinterface

• Open your webbrowser, enter the IP address of your GMSplus and login as admin (default password 123456)

| ← → C ▲ Not secure 192.168.100.12 ← ☆ ★ □ ● : | GeoSIG Ltd Web Interface × + | × | - 🗆 × |
|---|-------------------------------------|---|---------|
| GeoSig swiss made to measure Please fill in your Credentials: Username: admin Password: Iogin | ← → C ▲ Not secure 192.168.100.12 | ~ 论 ☆ | * 🗆 🕔 E |
| | | GeoSiG wiss made to measure Please fill in your Credentials: Username: admin Password: login | |

Choose tab Data Explorer, choose Status and Information from the dropdown and look for the latest logfile (file prefix LOG_)

| Home | Configuration | Status and Maintenar | nce Data Expl | orer Help | Logout | | to measure whet |
|---|--|---|--|----------------------|-----------------------|--------------------------|-----------------|
| Downloa | d | | | | | | |
| Data E | xplorer - 334 fil | es in Logfiles/ | | _ | | | |
| Status | and Information | | ✓ Reload The | Table will update | automatically every 2 | 20 seconds | |
| File N | ame | | 🔨 Туре | 2 | 🔨 Size | Modification Date | - |
| LOG 1 | 02833 20230621 | 000000.txt | Syste | m Messages | 503 KiB | Wed Jun 21 13:37:17 2023 | |
| LOG 1 | 02833 20230620 | 000000.txt | Syste | m Messages | 723 KiB | Tue Jun 20 23:59:52 2023 | |
| LOG 1 | 02833 20230619 | 000000.txt | Syste | m Messages | 856 KiB | Mon Jun 19 23:59:52 2023 | |
| LOG 1 | 02833 20230618 | 000000.txt | Syste | m Messages | 1.02 MiB | Sun Jun 18 23:59:58 2023 | |
| LOG 1 | 02833 20230617 | 000000.txt | Syste | m Messages | 968 KiB | Sat Jun 17 23:59:58 2023 | |
| LOG 1 | 02833 20230616 | 000000.txt | Syste | m Messages | 933 KiB | Fri Jun 16 23:59:56 2023 | |
| LOG 1 | 02833 20230615 | 000000.txt | Syste | m Messages | 864 KiB | Thu Jun 15 23:59:58 2023 | |
| LOG 1 | 02833 20230614 | 000000.txt | Syste | m Messages | 693 KiB | Wed Jun 14 23:59:44 2023 | |
| LOG 1 | 02833 20230613 | 000000.txt | Syste | m Messages | 768 KiB | Tue Jun 13 23:59:56 2023 | |
| LOG 1 | 02833 20230612 | 000000.txt | Syste | m Messages | 930 KiB | Mon Jun 12 23:59:58 2023 | |
| LOG 1 | 02833 20230611 | 000000.txt | Syste | m Messages | 987 KiB | Sun Jun 11 23:59:50 2023 | |
| LOG 1 | 02833 20230610 | 000000.txt | Syste | m Messages | 986 KiB | Sat Jun 10 23:59:50 2023 | |
| LOG 1 | 02833 20230609 | 000000.txt | Syste | m Messages | 760 KiB | Fri Jun 9 23:59:58 2023 | |
| LOG 1 | 02833 20230608 | 000000.txt | Syste | m Messages | 878 KiB | Thu Jun 8 23:59:54 2023 | |
| LOG 1 | 02833 20230607 | 000000.txt | Syste | m Messages | 1.13 MiB | Wed Jun 7 23:59:54 2023 | |
| LOG 1 | 02833 20230606 | 000000.txt | Syste | m Messages | 1.13 MiB | Tue Jun 6 23:59:54 2023 | |
| LOG 1 | 02833 20230605 | 000000.txt | Syste | m Messages | 991 KiB | Mon Jun 5 23:59:56 2023 | |
| LOG 1 | 02833 20230604 | 000000.txt | Syste | m Messages | 1.22 MiB | Sun Jun 4 23:59:58 2023 | - |
| | | | | | | | • |
| Device type: Serial numb Station code | GMSplus I er: 102833 S e: GS.GSGMS | Device date and time: Station description: | Wed Jun 21 13:37: GMSplus (6ch) - G | 34 2023 eoSIG Ltd | Device Sta | ate Summary 🔽 Context | Help 🕕 |

• You can download the file by clicking on it

3.3 Retrieve Logfiles from SD-Card

• Turn off the recorder by pressing the power button for 3 seconds



- Wait until the **RUN** LED stops flashing
- Remove the SD card from its slot (push to release)



- Insert the SD card in your PC's card slot
- Windows cannot detect all partitions on the SD card, so it may ask you to format the card: PLEASE DO NOT FORMAT THE CARD, OTHERWISE ALL RECORDED DATA WILL BE LOST!

| E Microsoft Windows | × |
|---|--------------------|
| You need to format the disk you can use it. | in drive R: before |
| Do you want to format it? | |
| Form | nat disk Cancel |

- Press [Cancel] if the above message appears
- The SD card should appear as drive named with the serial number of the recorder



• Check the Logfiles folder on the SD-card and look for the latest logfile (file prefix LOG_)



- Copy the file to your desired directory
- Safely remove the drive (Right-click -> Eject)



• Insert the SD card back in the recorder's card slot and turn it on pressing the power button