


How to get the firmware version out of the GMS-xx

In GeoDAS do a right click on the instrument and choose "More Information"



A new window opens. In the red marked section the firmware versions are displayed.

