




Ucon Quick User Manual

<p>Start Ucon</p>	
<p>Choose the right COM port and Baudrate</p> <p>For GMS-xx : 19200</p> <p>For GMSplus : 115200</p>	
	 <div style="display: flex; justify-content: space-around; margin-top: 20px;"> <div data-bbox="236 1032 480 1178" style="border: 1px solid black; padding: 5px; width: 30%;"> <p>Disconnects communication ("scrolling of the screen")</p> </div> <div data-bbox="528 1032 772 1178" style="border: 1px solid black; padding: 5px; width: 30%;"> <p>Reconnects communication ("starts scrolling of the screen")</p> </div> <div data-bbox="863 1032 1107 1178" style="border: 1px solid black; padding: 5px; width: 30%;"> <p>Scrolls through the different baudrates</p> </div> </div>
<p>Copies the screen buffer into the clipboard</p>	
<p>Opens a new text file by pressing "Editor"</p> <p>Paste the copied screen buffer content into the TXT file and store it</p>	