



Seismic Trip System

Overview

STS is a state-of-the-art seismic switch / trip system packaged as a 19" rack module consisting of Slot-in Modules (SiMs) inserted into vertical slots with a remote accelerometer connected to it.

It provides a set of highly reliable alarm contacts as outputs activated by exceedance of acceleration and/or based on state of health.

The STS combines the best of analog and digital technologies by utilising only hardware for the highly reliable alarms, and digital data acquisition for realtime digital monitoring, recording, playback, indepth processing and archiving of the sensor signal.

The unit provides full traceability of the sensor signal as well as the system logs, even if no trip was activated, with a buffer spanning to several weeks back.

All of the digital information can also be provided to remote users in the realtime, on demand, continuously and/or periodically.

Applications

- Automatic Seismic Trip System (ASTS)
- Detectors for integration in an ASTS
- Connection to an emergency shutdown system
- Nuclear Reactor protection
- Power Plant protection / stop
- Industrial process protection / stop

Key Features

- High reliability by using only hardware for the trip signal
- ► Field-proven GeoSIG accelerometer
- Trip on any individual sensor axis or on any vector sum of axes
- Highly flexible analog filtering for the sensor signal to fit project requirements
- Testable analog full chain from sensor up to alarm output
- Permanent monitoring of the connection to the sensor
- Easy maintenance and simple troubleshooting with rich number of test points and indicators
- Protected against misuse with key switch and permanent monitoring
- Permanent digital recording of full waveform
- Digital recorder based on field-proven GeoSIG CR-6plus system
- Realtime streaming of digital waveform and system status through Ethernet or serial interface
- Comprehensive dedicated software package
- Easily integrated in a standard 19" rack
- Independent and autonomous



STS Seismic Trip System

Specifications

Sensor

Model: STS-AC73*

True electro-mechanical force balance Type:

accelerometer

Dynamic range: 165 dB (per bin rel. full range)

Bandwidth: DC to 200 Hz Cross axis sensitivity: < 0.5%

IP66 stainless steel protective housing Protection:

24 VDC from STS module Power: Signal transmission: Current loop 4 to 20 mA *other sensor models are available on request

STS Rack - Analog Modules

Power Supply SiM

24 VDC (9-36 VDC) with DC/DC insulation DC input:

Power: 30 W max

Sensor Interface SiM

Input channels: 3 (for triaxial sensor) Input signal: 4 - 20 mA current loop

15 or 24 VDC Sensor power:

Analog Filters SiM

highpass (HP) and Lowpass (LP) Type:

up to 6 poles each

Bandwidth: 0.5 - 10 Hz by default, adjustable per project

Test mode: Filter disable switch for testing

Trip Level 1 / 2 Comparator SiM

One per each sensor axis, totally 3 Comparators:

Optional: Vector calculation (analog) before comparison

Level adjustment: By potentiometers and dip-switches

Settings verification: Test points on front panel

Alarm Logic SiM

Fully discrete, no firmware Type:

Number of alarms: 4, each with jumper selectable source Restart: A restart timer is used to avoid random condition during power up, especially for low

frequency

Test, Acknowledge, Reset buttons for alarms Control panel:

with security key

One per each alarm and power status Status lamps:

Alarm Outputs SiM

Coil status: Normally energised or not, user selectable Selectable from 0.8 to 5, 15 or 30 seconds Hold timer: Alarm type: Latched with acknowledge/reset or hold time

Relays Interface Board

Relays type: Solid state opto-relays

Contacts type: 2 inverters

Contact verification: Resistors in parallel and series

STS Rack - Digital Modules

Data Handling SiM

Continuous and/or event trigger-based Data recording:

Trigger type: Level or STA/LTA trigger

Pre-/Post-event time: 1 to 720 / 1 to 7200 seconds, typical Trigger filtering: User configurable LP, HP or bandpass (BP) GSBU, SeedLink (Earthworm compatible) Data stream: Storage memory: 64 GByte removable microSD card, or higher with policy-based intelligent management

miniSEED, optionally with extended

GeoSIG Ltd Wiesenstrasse 39, 8952 Schlieren, Switzerland. Tel.: +41 44 810 21 50

Recording format: information encapsulated into blockette 2000

Digitiser SiM

Channels: 3 channels per SiM (for triaxial sensor) A/D converter: 24 bit Δ - Σ per channel with FIR anti-aliasing

Up to 1000 SPS Sampling rate:

Interface Digital / Analog

Unidirectional analog to digital with insulation Type:

Self-Test and Self-Monitoring (Analog and Digital) The ERROR alarm by analog part:

The alarm can be activated from various sources: a board is removed; a power supply has an under-voltage condition; a sensor signal is in error; or an alarm SiM has a permanent trip.

TEST alarm by analog part:

When the TEST button is pressed on the unit, an alarm is activated. Same if the test line to sensor activated for any

reason or the filter switch set to disabled mode.

The digital part receives the alarms status and sends it with the measured acceleration signal to the communication channel. A SOH is built by the digital system and transmitted to the user.

Time base (Digital)

Internal: Intelligent Adaptive Real Time Clock (IARTC)

NTP (requires Ethernet connection) External: Std. TCXO accuracy: ± 0.5 ppm (15 s/year) @ +25 °C

Accuracy with NTP: < ± 4 ms typical, assuming reasonable access

to NTP servers

Communication Channel (Digital)

Ethernet TCP/IP for streaming and SSH or Standard:

web interface access

Optional: Serial port for unidirectional streaming data

and system status

User Interface (Analog and Digital)

Analog

Clear indicators and push-buttons allow the operator to easily perform tasks. The unit is also made to operate independently from any operator

action. The front panel is populated with test points and

indicators to simplify maintenance and troubleshooting tasks. The setting of the trip system (levels, duration, ...) is achieved by adjusting

potentiometers.

Digital

An intuitive web interface is available for easy configuration with any web browser. Alternatively the configuration file in XML format can be edited on site through the instrument console, exchanged by replacing the memory card, remotely from a server or through SSH. Even if the configuration file can be manually edited at any time, a tool is provided to edit it securely.

When using the serial port for sending data (streaming) and status to an archiving system, the system can be operated only locally through the front panel serial console or connecting directly to the Ethernet port. This gives the full control of the digital part of the system only locally. At all times the analog part remains independent.

Alarms output (Analog)

Alarms: Trip level 1 and 2, error and test mode 2 independent relay contacts for each alarm Contacts:

> (NO and NC contacts available, normally energised / non-energised selectable)

0.8 to 5, 15 or 30 seconds (fixed) Relay hold-on:

other values on request

Suitable for a low voltage control. In case large Contacts:

loads must be switched then external relays

should be implemented

50 V / 50 mA Max voltage:

Other relays and output range on request Option:

Environment / Housing

 0° C to +50° C Operational temp: -40° C to $+85^{\circ}$ C Storage temp:

Humidity: 10% to 90% (non-condensing)

Rack dimensions: 19" rack, 3 U, 240 mm depth + connector

and front handle

IP20, housing with higher protection Protection:

available on request









